


Side View

Fabricating Instructions.

1. Cut PVC tubing to proper length using the counter/cutter. Insure cut is square by pulling tubing straight out from counter across cutter when cutting.

XXXXX = Part Number/Material

| | | | | | |
|---|--|------------------|---------------------------|-----------|-----|
|  | Tel: +219-464-2027 | Designed By: BAP | Tbg,PVC,12.7IDx17.5OD,Clr | | |
| | Fax: +219-464-8646 | Date: 8/27/97 | | | |
| | Visit us on the Web at www.ufsc.com | Approved By: | UFS Part No. 060002 | Sheet: | 1/1 |
| | | Date: | | Revision: | 0 |
| <small>THIS MATERIAL IS THE CONFIDENTIAL PROPERTY OF UFS CORPORATION AND SHOULD NOT BE USED IN ANY WAY DETRIMENTAL TO THE CORPORATION'S INTEREST. MATERIAL SHOULD NOT BE COPIED OR REPRODUCED IN PART OR IN WHOLE, AND INFORMATION FROM IT SHALL NOT BE FURNISHED TO OTHERS WITHOUT WRITTEN PERMISSION. ALL RIGHTS OF DESIGN AND INVENTION ARE RESERVED BY UFS CORPORATION. MATERIAL TO BE RETURNED UPON REQUEST.</small> | | | Units: | mm[in] | |
| | | | Scale: | None | |