

Installation Reference

Topic: Field Fix (704006)

Please read all the instructions listed below carefully to familiarize yourself with the project before attempting to perform any of the work or unpacking any further.

Required Materials (included)

- P/N 095059 Bulkhead
- Epoxy
- P/N 850003 Plug
- P/N 330001 Bolt
- P/N 340001 Nut
- P/N 350001 Washer

Required Tools

- File (to de-burr tab if necessary)
- 1/2" Wrench
- 17 mm Wrench

Please use the following instructions to install P/N 095059 Bulkhead on to P/N 704006 ME Cell.

1. Insert Plug into Boss on Side of ME Cell.



until both Anode Tab holes are Exposed.



2. Make sure holes in Anodes have no burrs. If burrs are present, file them down to allow easy installation of Bulkhead.



5. Connect return tubing to hose barb on P/N 704006.



3. Slip supply tubing into hole in Bulkhead and pull tubing thru hole and align Anode Tab with the slot in Bulkhead.



6. Make your electrical connection. Connect pigtail to P/N 704006 using P/N 330001, P/N 340001 and P/N 350001.



4. When Anode Tab is aligned with slot in Bulkhead, push Bulkhead into top of P/N 704006

7. Fill top portion of P/N 704006 with epoxy until it reaches approximately 1/4" below top of P/N 704006.

For more information see the original manual that came with the equipment or call UFS.