



**UFS Corporation**  
330 North 400 East  
Valparaiso, IN 46383-9704 USA  
PH: 219-464-2027 FAX: 219-464-8646  
www.ufsc.com  
email: service@ufsc.com

# Installation Reference

---

## Topic: Installing PN 701029

*Please read all the instructions listed below carefully to familiarize yourself with the project before attempting to perform any of the work or unpacking any further*

### Required Materials

---

- 5/16 Bolt SS (4 each)
- 5/16 Nut SS (4 each)
- 5/16 Washer SS lock or compression (4 each)

### Required Tools

---

- 1/2" Wrench (2 each)

1. **IMPORTANT** – Do not open the air tight bag until the Membrane Shell is ready to be installed.
2. Carefully remove the roof Cell from the air tight, sealed bag. To avoid damaging the Cell, do not use anything sharp to open the bag.
3. Carefully remove the white paper towels from the Membrane Shell. The towels were used to keep the Membrane moist during the shipment. Use rubber gloves to remove the paper towels. To avoid damaging the Membrane, do not use any sharp objects to remove the paper towel.
4. Place the Cell on its side to avoid damaging the Membrane or the tab. Do not lay it flat.
5. Use only stainless steel hardware when installing the roof Cell.

**For more information** see the original manual that came with the equipment or call UFS at the phone number shown above.