



# Installation Reference - Membrane Electrode

## Topic: Some Electrical Assembly Required

Please read all the instructions listed below carefully to familiarize yourself with the project before attempting to perform any of the work.

### Required Materials

- As required

### Required Tools

- As Required

In some instances, it is not possible to completely assemble the product(s) before shipping. Therefore, some electrical assembly may be required.

### Instructions

1. Refer to the attached electrical wiring diagram.
2. Make sure all power is turned off and the DC rectifier is locked out before proceeding.
3. Follow any appropriate local, state or federal electrical code.
4. Only a qualified electrical technician should perform any electrical work.

For more information see the original manual that came with equipment or call UFSc (219) 464-2027 ext. 24.

**UFS Corporation. . .dedicated to providing quality, innovative solutions to the electrocoating industry.**

Topic: *Some Electrical Assembly Required*  
(P/N 993117)

Think and act in a safe manner. Always disconnect power and use a lockout before you work on the E-coat system, or any of the related subsystems. Observe any confined space conditions. Use the appropriate safety equipment and clothing for the task.

UFS Corporation  
330 North 400 East  
Valparaiso, IN 46383 USA

Phone: 219-464-2027  
Fax: 219-464-8646  
Email: info@ufsc.com

