

Service Reference

Topic: Using Bulkhead Fittings

Please read all the instructions listed below carefully to familiarize yourself with the project before attempting to perform any of the work or unpacking any further.

Required Materials

- Teflon Tape

Required Tools

- 20 mm Wrench

Auto Lock Fittings are comprised of the following parts: tube stem, hose barbs, and elbows.

1. Apply Teflon tape to the tube stem(s) threads.
2. Using the 20 mm wrench, screw the tube stem into the 3/8" threaded opening.
3. Insert the 90° elbow on to the tube stem. Push down until it locks in place. Once the elbow is in place, it cannot be removed from the tube stem. **TIP:** If the tube stem needs to be replaced, unscrew it from the part. Call UFSc for replacements.
4. Insert the hose barb into the other end of the elbow. Suppressing the elbow and pulling out the hose barb can replace this part.

For more information see the original manual that came with the equipment or call UFSc at the phone number shown above.

